

Poly – Setting Up WiFi USB Dongle

Inserting Dongle

1. Insert the Poly Wi-Fi wireless USB network adapter into the USB port of your VVX phone. The USB port can be found on the underside of the phone, behind the screen.



Enabling Wi-Fi

1. Go to **Settings > Basic > Wi-Fi**.
2. Select **Wi-Fi**, then select **On**.
3. Select **Yes** to reboot the phone.

After the phone reboots, Wi-Fi is enabled.

The phone scans for wireless networks and lists any that are available. If the phone does not automatically scan, select Scan to manually initiate a Wi-Fi network scan.

Connect to a Secured Wireless Network

Poly UC software supports different wireless network security profiles like Personal and Enterprise modes for better security. You can select a PSK or an enterprise-based security option to connect your VVX phone to a secured wireless network.

1. Go to **Settings > Basic > Wi-Fi**.
2. Do one of the following:
 - **For a WPA(2)-PSK network:** enter the Password.
***Most Common
 - **For a WPA2-enterprise network:** enter User ID and Password.
3. Select **Connect**.

The phone connects to the Wi-Fi network and displays the Wi-Fi connection status on the Menu and Home screens.

Supported Enterprise Security Modes:

- EAP-PEAP/MSCHApv2
- EAP-FAST
- EAP-TLS

Disconnect from a Wireless Network

1. Go to **Settings > Basic > Wi-Fi**.
2. Select the **connected wireless network SSID** from the list.
3. Select **Disconnect**.

You Should Know

1. Enabling Wi-Fi automatically disables the LAN (Ethernet) port.
2. You cannot use Wireless and Wired connections simultaneously to connect your VVX phones to the network.
3. WEP is not supported.
4. VVX phones use 2.4GHz or 5GHz default radio bands.