
## Yealink — Reset W60 Cordless Base to Factory Default

## Hard Reset

In order to reset a Yealink DECT Base to the Default Values using Hard Reset, please perform the following steps:


1. Unplug the power supply or if there is no power supply unplug the Ethernet cable.



2. Press the Paging Button, keep it pressed until 3 lights are all lit.



4. Once all 3 lights are lit, release the Paging Button.



- 5. Restart the Base, by unplugging the power supply or power over ethernet cable.
- 6. Once Base comes back online you are ready to pair the handsets.